KEYLESS 1 USER INSTRUCTIONS

TO LOCK


TO UNLOCK

1. Close the door.

- 1. Re-enter your code.
- 2. Make sure knob is pointing up to \triangle , then set any 4-digit code.
- 2. Turn the knob up to \triangle .
- 3. Open the door.

3. Turn knob to △.

- 4. Keeping the knob facing \triangle , scramble the dials for the next user.
- Scramble the dials.









MANAGERS EMERGENCY REMOVAL:

www.keyless.co/keyless1-instructions/emergency/





